

## Knowledge Base

### Line, microphone or Hi-Z instrument input not working

original release: 2019-11-02 | ID: KB00273EN



Our U22 XT has a switch on the backside that is used for selection to use the inputs on the front or the backside of the device. Please check, if the inputs on the front (microphone / instrument) or the line inputs (RCA connectors) on the back are selected.

