

USB 2.0 MIDI Interface Cable
with 2 I/O ports

MIDIMATE eX

User's Guide



Introduction


Thank you for choosing the ESI MIDIMATE eX.

MIDIMATE eX is a convenient USB 2.0 MIDI interface cable with up to 32 input or 32 output channels for PC and Macintosh systems. With MIDIMATE eX you can obtain perfect MIDI timing and performance at an extremely affordable price.

Features

- USB MIDI interface with 2 MIDI connectors, each can work as independent input or output
- high-speed connection to USB 3.0, 2.0 or 1.1 port of PC or Macintosh
- bus powered, requires no external power supply
- no driver needed for Windows XP, Windows Vista, Windows 7, Windows 8.1, Windows 10 and Mac OS X (32 and 64 bit)

Connectors



MIDIMATE eX features two separate MIDI connectors (**1** and **2**) and a USB connector (**3**). The MIDI connectors are labeled 1 and 2 and each of them can connect to the MIDI input of a device (then they work as an output) or to the MIDI output of a device (then they work as an input). The USB connector connects to the USB port of your PC or Mac.

Installation

Find a USB port on your computer. If your computer has a USB 2.0 or 3.0 port, please use this port for best performance. MIDIMATE eX also works on a USB 1.1 port. If you are unsure, check the documentation of your computer. Make sure your computer is switched on. Connect the USB connector of MIDIMATE eX to the USB port on your computer. No driver installation is needed and you can start using it in seconds.

Under Windows XP, you can check if MIDIMATE eX has been installed correctly, by going to *Control Panel > Sounds & Multimedia > Audio > MIDI Playback*. You will see 2 new USB MIDI entries in the MIDI port selection. Note that this dialog does not exist under Windows Vista, Windows 7, Windows 8.1 or Windows 10. Please start your MIDI application (like a sequencer or notation software) to check the MIDI ports there.

Under Mac OS X, you can launch the *Audio MIDI Setup* application. MIDIMATE eX will be listed under MIDI Devices with 2 I/O ports.

Each MIDI connector of MIDIMATE eX has its own MIDI port entry for input and for output in your MIDI application.

General Information

Trademarks: ESI, MIDIMATE and MIDIMATE eX are trademarks of ESI Audiotechnik GmbH. Windows is a trademark of Microsoft Corporation. Other product and brand names are trademarks or registered trademarks of their respective companies.

Correspondence: For technical support inquiries, contact your nearest dealer, local distributor or ESI support online at www.esi-audio.com.

Disclaimer: All features and specifications subject to change without notice. Parts of this manual are continually being updated. Please check our web site www.esi-audio.com occasionally for the most recent update information.