

Knowledge Base

Installation of Waveterminal 192 under Windows Vista & 7/8 (from v1.09)

original release: 2014-09-27 | ID: KB00209EN




Introduction

This text describes how to install the Waveterminal 192L , Waveterminal 192M and Waveterminal 192X driver under Windows 8.1 (32- or 64-bit) with driver versions starting from version 1.09. The process is virtually the same for Windows Vista, Windows 7 and Windows 8. A description of the installation with earlier drivers (up to version 1.08) can be found here.

Installation

Make sure that you have downloaded and unzipped the driver file . Install the Waveterminal 192 hardware in your computer if not already done. If you are just booting your system, Windows might detect the hardware as a new device and a *Found New Hardware* dialog will appear automatically. If so, click *Cancel*.

To start the installation, launch the setup program, which is an .exe file that is inside the driver download, by double clicking on it. Typically the filename is something like *WT192_LXM_vX.YY_setup.exe* where *X.YY* is the version number of the driver. When launching the installer, Windows might display a security message. Make sure to allow the installation. After that, the following dialog will appear:



Click *Next* and then the following dialog will appear:




Knowledge Base

Installation of Waveterminal 192 under Windows Vista & 7/8 (from v1.09)

original release: 2014-09-27 | ID: KB00209EN



Now click *Install*. Files are now being copied. After some time an additional dialog will appear:




Confirm this by clicking *Next*. Again some files are being copied and typically you will be prompted with a *Windows Security* message like this:

Knowledge Base

Installation of Waveterminal 192 under Windows Vista & 7/8 (from v1.09)

original release: 2014-09-27 | ID: KB00209EN



Confirm it by clicking *Install*. After a while the installation then will be completed and the following dialog will appear:



Once you see this, click *Finish*. On some systems it might be good to reboot the computer manually now. You will see that the Waveterminal 192 control panel is now automatically being loaded and displayed - the installation is finished.

Uninstallation

In case you need to uninstall the driver at a later time, you will find it under the list of installed *Programs* in Windows *Control Panel* . You can simply remove it there.

