

Knowledge Base

Can I use more than one U86 XT/U168 XT in one system?

original release: 2016-12-11 | ID: KB00252EN



No. Only one U86 XT or U168 XT hardware can be used with one computer at a time.