

# ESP1010: Readme

unified driver and control panel for Windows Vista, Windows 7

version: 1.07 | date: 2009-10-23 | filename: ESP1010-x2v-v1\_07.zip | product: ESP1010




## ESP1010 under Windows 7 and Windows Vista

This driver is only intended for Windows 7 32-bit/64-bit and Windows Vista 32-bit/64-bit, other versions of Windows are not supported. If you have installed a previous ESP1010 driver already, you need to remove it first - this is described below in the uninstallation section. Then you can proceed with driver installation. The pictures are referring to Windows Vista, the installation under Windows 7 is virtually identical however.

### Installation

Make sure that you have downloaded and unzipped the driver file. Install the ESP1010 hardware in your computer or if you have previously uninstalled an older driver, reboot your system. When booting the system, Windows will detect the hardware as a new device and a *Found New Hardware* dialog will appear automatically.

Note: if the hardware is already installed in your PC but you did not install a driver, please find the entry for an unknown *Multimedia Audio Controller* in *Control Panel > System > Device Manager*. Right click on that and select the driver update option.



Make sure to click on *Locate and install driver software (recommended)*. The following dialog will appear after some time:




# ESP1010: Readme

unified driver and control panel for Windows Vista, Windows 7

version: 1.07 | date: 2009-10-23 | filename: ESP1010-x2v-v1\_07.zip | product: ESP1010



Click on *I don't have the disc. Show me other options.* to continue. Please note that it might take some time until the next dialog appears:



Proceed by clicking on *Browse my computer for driver software (advanced)* . The following dialog will be shown:




# ESP1010: Readme

unified driver and control panel for Windows Vista, Windows 7

version: 1.07 | date: 2009-10-23 | filename: ESP1010-x2v-v1\_07.zip | product: ESP1010



Click on *Browse...* and then select the folder that contains the unzipped driver. Click *OK* and then *Next*. The driver installation will now start. After some time, you will be prompted to confirm a *Windows Security* message. Make sure to click *Install* to continue.




# ESP1010: Readme

unified driver and control panel for Windows Vista, Windows 7

version: 1.07 | date: 2009-10-23 | filename: ESP1010-x2v-v1\_07.zip | product: ESP1010



The driver installation will now be completed until the following dialog appears:



# ESP1010: Readme

unified driver and control panel for Windows Vista, Windows 7  
version: 1.07 | date: 2009-10-23 | filename: ESP1010-x2v-v1\_07.zip | product: ESP1010




Congratulations - you can now use ESP1010 in your system. The control panel will appear after a few seconds in the task notification area of the taskbar.

## Uninstallation

To uninstall the driver, you can use an utility that is included with the driver. Make sure you have unzipped

the driver file. Open Windows Explorer and find the correct driver folder. If you are using Windows Vista/7 32-bit, go to the *win32* folder and launch *UnInstall\_32* by double clicking on it. If you are using Windows Vista/7 64-bit, go to the *x64* folder and launch *Uninstall\_64* by double clicking on it. When launching the uninstaller, Windows might prompt a security message. Make sure to allow the uninstallation. The following dialog will appear:



Click on *Uninstall*. After a few seconds, this dialog confirms the procedure:



Note that in some cases, Windows will ask you if the uninstaller worked, confirm this with *This program installed correctly*. To re-install the updated driver (as described above

), you need to reboot the system.

