ESI USB MIDI driver v1.0 Installation

Below installation procedure is for the ESI RoMI/O. However, Driver installation procedure is same for M4U and M8U.

1. Windows XP/2003

Just plug the USB device, and run Romio.exe (M4U.exe, M8U.exe). It's the Auto installation.

2. Windows 2000/ME

Don't plug the USB device before install the driver. Otherwise, your system will be automatically rebooted.

- 1) Unplug the USB device from your system.
- 2) Run Romio.exe (M4U.exe, M8U.exe).

And click 'Yes' follow the instruction.



		6
cense Agreement Please read the following license agreement	carefully.	
Press the PAGE DOWN key to see the rest	of the agreement.	62
LICENSE:		
Use the program on a single machine and o machine-readable or printed form for backu, the program on the single machine.		
Transfer the program and license to anothe agrees to accept the terms and conditions transfer the program, you must at the same copies, whether in machine readable or prir	of this Agreement. If you ime either transfer all	
Do you accept all the terms of the preceding		u choose No, the
setup will close. To install ROMIO, you mus	accept this agreement.	
IShield		_
	< <u>B</u> ack <u>Y</u> e	es <u>N</u> o
allShield Wizard		
oose Destination Location		
oose Destination Location		
oose Destination Location Select folder where Setup will install files.	er.	
allShield Wizard oose Destination Location Select folder where Setup will install files. Setup will install ROMIO in the following fold To install to this folder, click Next. To install another folder.		owse and select
Dose Destination Location Select folder where Setup will install files. Setup will install ROMIO in the following fold To install to this folder, click Next. To install		owse and select
Dose Destination Location Select folder where Setup will install files. Setup will install ROMIO in the following fold To install to this folder, click Next. To install		owse and select
Dose Destination Location Select folder where Setup will install files. Setup will install ROMIO in the following fold To install to this folder, click Next. To install another folder.		owse and select B <u>r</u> owse
Dose Destination Location Select folder where Setup will install files. Setup will install ROMIO in the following fold To install to this folder, click Next. To install another folder.		

With Windows 2000 and XP installations, a message might appear stating "The software has not passed Windows Logo testing to verify its compatibility with Windows XP." Though the message appeared, the driver is completely tested and verified by ESI and is safe to use. You can ignore the message and just click 'Yes'.

Digital Signature Not Fou	ind	×
3	The Microsoft digital signature affirms that software has been tested with Windows and that the software has not been altered since it was tested.	4.
	The software you are about to install does not contain a Microsoft digital signature. Therefore, there is no guarantee that this software works correctly with Windows.	
う歴史	RoMI/O by ESI	
	If you want to search for Microsoft digitally signed software, visit the Windows Update Web site at http://windowsupdate.microsoft.com to see if one is available. Do you want to continue the installation?	
-	Yes <u>N</u> o <u>M</u> ore Info	
Information		×
The driver wa	s successfully installed. Plug your USB MIDI device no	w.

3) After finishing the driver installation, plug the USB device to your computer.



In the case of Windows 2000, You may see this message again. Simply ignore the message and just click 'Yes'.

been altered since it was tested.
The software you are about to install does not contain a Microsoft digital signature. Therefore, there is no guarantee that this software works correctly with Windows.
RoMI/O by ESI If you want to search for Microsoft digitally signed software, visit the Windows Update Web site at
http://windowsupdate.microsoft.com to see if one is available. Do you want to continue the installation?

4) Go to 'My computer-> Console -> Sounds and multimedia Properties -> MIDI tab. Select RoMI/O (M4U, M8U) as your playback device.

Sounds	Audio Hardw	vare	
Sound	Playback		
Ch.	Preferred device:		
A V	No Playback Devices		¥.
		⊻olume	Advanced
Sound	Recording		
2	Preferred device:		
13	No Recording Device	s	7
		V <u>o</u> lume	Advanced
MIDI M	usic Playback		
-	Preferred device:		
	2-RoMI/O MIDI		•
	1-RoMI/O MIDI 2-RoMI/O MIDI		
	Land 0		-
✓ Use c	nly preferred devices		

* In some case of Windows 2000, after rebooting your computer, you may find this message again. Just ignore and click 'Yes'.

