

High Quality 4-in / 4-out
PCIe Audio Interface



User's Guide



ESI - Copyright © 2011

Revision 2, September 2011

www.esi-audio.com

INDEX

1. Introduction.....	4
2. Description of MAYA44 XTe.....	4
2.1 PCIe card connectors	4
2.2 Minimum System Requirements.....	5
3. Hardware Installation	5
3.1 Preparation for Hardware Installation	5
3.2 PCIe Card Installation.....	6
4. Driver Software Installation	7
4.1 Windows XP	7
4.2 Windows Vista & 7.....	9
4.3 Mac OS X	10
5. Connecting External Devices	10
5.1 MAYA44 XTe Line Connectors.....	10
5.2 Connection Examples	11
6. MAYA44 XTe Control Panel.....	13
6.1 Pull-Down Menus	13
6.2 Input Section	14
6.3 Output Section	14
6.4 Digital Section	15
6.5 DirectWIRE	15
7. Audio Applications.....	17
7.1 Windows Multimedia Setup.....	17
7.2 Mac OS X Audio MIDI Setup	17
7.3 Cubase LE 6.....	18
8. Specifications	18
9. General Information	19

1. Introduction


Thank you for choosing the ESI MAYA44 XTe, a high quality 24-bit / 96 kHz 4-in / 4-out PCIe audio interface, providing a number of powerful and amazing features optimized for home recording on a professional quality level and for various DJ applications.

The card can easily be used by home users making their first steps in computer audio as well as by professionals who produce music on a budget, looking for a professional, yet affordable, PCIe audio solution.

MAYA44 XTe provides 2 stereo analog line inputs, 2 stereo line outputs, a microphone input with +48V phantom power and preamp, a Hi-Z guitar instrument input, as well as an optical S/PDIF output and an optical S/PDIF input.

2. Description of MAYA44 XTe

2.1 PCIe card connectors



1. **INPUT 1/2:** analog line input connector (stereo) / microphone input (mono)
2. **INPUT 3/4:** analog line input connector (stereo) / Hi-Z instrument input (mono)
3. **OUTPUT 1/2:** analog line output connector (stereo) / headphone output (stereo)
4. **OUTPUT 3/4:** analog line output connector (stereo) / headphone output (stereo)
5. **Optical In:** optical digital S/PDIF input
6. **Optical Out:** optical digital S/PDIF output

2.2 Minimum System Requirements


- Intel CPU or equivalent and compatible AMD CPU
- 512 MB RAM
- Direct X 8.1 or higher
- one available PCIe x1 (or higher) slot
- DVD-ROM drive (for Cubase LE 6 installation)
- internet connection (for Cubase LE 6 activation)
- recent version of Microsoft Windows XP (SP2 or higher) or Windows Vista/7 (32-bit & 64-bit) or Mac OS X (10.6 or higher)
- the latest chipset and mainboard utility drivers and system updates must be installed

3. Hardware Installation

3.1 Preparation for Hardware Installation


The MAYA44 XTe PCIe card and other components in the computer can be damaged easily by electrical shock. You should use an anti-static device that can discharge the static electricity of your body to avoid potential static damage to the cards. If you do not feel capable of installing a PCIe card into your computer please contact a computer specialist.

Turn off the computer power and remove the power cable from your computer power supply.



Disconnecting the Power Cord

Refer to your computer user's manual and remove the computer cover. Make sure that you have an available PCIe slot on your motherboard to install the MAYA44 XTe.




Removing the computer cover

To avoid possible static shock damage to the computer parts, discharge it by touching the computer case or something grounded. We recommend you use an anti-static device such as an anti-static wristband.

When holding the MAYA44 XTe card, touch only the guide or the edge of card. Do not grab the card by the board or connector.


3.2 PCIe Card Installation

Find an empty PCIe slot on the motherboard. If you are unsure, please check the manual of your mainboard or computer to identify the PCIe slot, or consult a computer specialist. There are different types of PCIe slot, MAYA44 XTe will work both in a shorter PCIe x1 and in any longer higher level PCIe slot, however not in old standard PCI slots.




Typical PC Motherboard Slot Configuration

If a faceplate or cover is behind the PCIe slot, you can remove it by removing the screw holding it in place or by prying it off with a screwdriver.



Removing the slot faceplate

Insert the MAYA44 XTe card into the PCIe slot, firmly pushing the card into the slot until it is seated securely. Replace the screw, and tighten.



MAYA44 XTe Installed in a PCIe x1 slot, next to two standard PCI slots

Once finished, close the computer case.

4. Driver Software Installation


Before installing the drivers of MAYA44 XTe, we recommend to check on the download section of www.esi-audio.com for updated drivers.

4.1 Windows XP

Turn on your computer. Windows will automatically detect a new device installation and the *Found New Hardware Wizard* window will appear as seen on the following picture on the left.



Select *No, not this time* and click *Next*. On the following dialog select *Install from a list or a specific location (Advanced)* and click *Next*. The dialog below will appear.



Make sure to select *Search for the best driver in these locations* and below that only select *Include this location in the search*. Via *Browse*, you can select the folder that contains the driver data. If you install from the original CD, select your CD-/DVD-drive and the \Windows folder. Otherwise select the folder that contains the unzipped driver data from our website. Once done, click *Next*.



Windows will now prompt you to confirm the Windows Logo testing in the *Hardware Installation* dialog with *Continue Anyway* before the driver installation proceeds. After some time, the installation of the *ESI MAYA44 XTe Controller* device will be completed and you need to click *Finish*.

Once this is done, the *Found New Hardware Wizard* will automatically appear again. Please follow the exact steps one more time, this time to install the *ESI MAYA44 XTe Audio* device. After that is finally confirmed on the last dialog via *Finish*, the MAYA44 XTe driver software has been completely installed. To confirm this, please check if the ESI icon is displayed in the taskbar notification area as shown below.




If yes, the driver installation has been completed successfully. Note that on some systems the computer has to be rebooted (Windows will display a message in that case) before everything is completed.

4.2 Windows Vista & 7



Turn on your computer. Windows will automatically detect a new device installation and the *Found New Hardware* window will appear as seen on the following picture.




Select *Locate and install driver software (recommended)*. Insert the driver CD only if you are installing the original driver from the CD. If you are installing an updated driver from our website, proceed by clicking on *I don't have the disc. Show me other options.* on the following dialog.



If the following window on the left will appears, click on *Browse my computer for driver software (advanced)* in order to show Windows where the driver files are located. The dialog on the right will appear.



Via *Browse*, you can select the folder that contains the driver data. If you install from the original CD, select your CD-/DVD-drive and the *\Windows* folder. Otherwise select the folder that contains the unzipped driver data from our website. Once done, click *Next*.



Windows will now prompt you to confirm the installation in the *Windows Security* dialog with *Install* before the driver installation proceeds. After some time, the installation of the *ESI MAYA44 XTe Controller* driver will be completed and you need to click *Close*.

To confirm the completion of the installation, please check if the ESI icon is displayed in the taskbar notification area as shown below.



If yes, the driver installation has been completed successfully.

4.3 Mac OS X

To install MAYA44 XTe under Mac OS X, insert the CD into your system and navigate in Finder to the *Mac OS X* folder on the CD. Alternatively you can download the latest version of the driver from our website. You will find a file called *MAYA44_XTe-Mac-vx_yy.dmg* (where *x_yy* stands for the driver version number). Double click on this file and a new window with the installer opens.


Now double click on the MAYA44 XTe driver installer and follow the instructions on screen. Once the installation is completed it is recommended to reboot your system.

Via *Utilities* -> *Audio MIDI Setup* you can check if the driver has been installed correctly.

5. Connecting External Devices

5.1 MAYA44 XTe Line Connectors

The line input and line output connectors of MAYA44 XTe are unbalanced stereo, using a 1/4" TRS connection. This means that in order to have separate stereo connectors, you might need to use a special cable that is shown on the following picture. It converts one stereo (seen on the left) 1/4" jack with two mono (typically left/white and right/red) 1/4" jacks for the separate mono signals.




The tip of the stereo TRS connector is connected with the tip of the left TS connector. The ring of the stereo TRS connector is connected with the tip of the right TS connector. The sleeve is connected with sleeve / ground of both channel connectors.

The same type of cables are typically used as so-called ‘insert-cables’ to connect effects units to many mixing consoles. This information might help you when you want to make or purchase such a cable.

5.2 Connection Examples


Line Inputs

MAYA44 XTe has two stereo line inputs (*INPUT 1/2* and *INPUT 3/4*) that can be connected to any device with regular unbalanced -10dBv line output such as the output of a mixing console, a CD or MD player, a sound module, a keyboard with sound engine, a synthesizer or others.



Instrument and Microphone Inputs

MAYA44 XTe has a built in professional microphone preamp with +48V phantom power support. You can connect a dynamic microphone as well as a condenser microphone to the top input. *INPUT 1/2* has to be switched to accept microphone signals in the Control Panel (see chapter 6 of this manual). If you use a condenser microphone, you need to enable +48V in the Control Panel as well. Please make sure to use a fully balanced XLR to TRS microphone cable.




In addition, MAYA44 XTe has a Hi-Z instrument input that can be used for a direct connection to an

electric guitar. *INPUT 3/4* has to be switched to accept guitar signals in Control Panel (see chapter 6 of this manual). Note that the input signal will be mono only.

Line and Headphone Outputs


The MAYA44 XTe stereo line outputs (*OUTPUT 1/2* and *OUTPUT 3/4*) can be connected to external devices with line input such as multi track recorders, a HiFi stereo system, active monitoring speakers, a power amplifier or analog mixing consoles. As the two stereo output pairs are totally independent, they can be connected to different channel of a mixer or to different devices altogether and different audio signals can be sent out to them simultaneously. This is especially nice in situations where you need two independent stereo signals, for example in a DJ setup for the main and pre-listen signal.

In addition, both stereo line outputs can be enabled used as headphone outputs.




S/PDIF I/O

MAYA44 XTe provides optical S/PDIF digital in & outputs. You can use this to send signals to the digital input of an MD Player, CD Recorder, DAT-Recorder or Digital Mixer. With the digital input, you can record signals from devices with an optical S/PDIF output. The Control Panel (see chapter 6 in this manual) allows you to control S/PDIF input and output parameters.



6. MAYA44 XTe Control Panel

This chapter describes the MAYA44 XTe Control Panel. To open the panel double click on the ESI icon in the task notification area (or by double clicking on the icon in the *Applications* folder when using Mac OS X). The following dialog will appear:



6.1 Pull-Down Menus

File – Exit: will close the MAYA44 XTe control panel window but it will not shut down the control panel. You can always launch control panel the by clicking ESI icon on the system tray.

Config – Mouse Wheel: controls the increment at which the volume is adjusted when using a mouse wheel. The adjustment step is from 1 to 8.

Config – Latency: adjusts the latency (also often referred as buffer size) of MAYA44 XTe. A lower latency is achieved by selecting smaller sample size which is ideal for software synthesizer and precise timing recording. However, the latency is also limited by your system performance. For most recording applications, select a sample size between 64 ~ 512, select 256 or higher on slower systems or at very high system load. Buffer size 48 is reserved only for very fast and reliable ASIO driver environments on fast computer systems. Note that this value has to be setup before launching any audio application using MAYA44 XTe.

Config – Factory Default: resets the control panel to default settings.

Config - Always On Top: this enables to place the control panel on top of every open window, which makes it easy to work with MAYA44 XTe and other audio applications simultaneously.

Config – Link: links the L-R faders for stereo operation. Unselect the entry, if you need to control the levels of left and right channels independently.

DirectWIRE: opens the DirectWIRE dialog, described in section 6.5 of this manual.

Help – About: allows you to check current driver information.

6.2 Input Section

Monitor buttons: with this button you can enable the input monitoring for the corresponding input channel. When enabled, the input signal is audible via the output.

Line/Mic/+48V/Digital selection: by default, input channel 1/2 is processing the stereo line input signal coming in from *INPUT 1/2* (when *LINE* is selected). However, it can also be switched to process the mono input signal from a microphone connected to MAYA44 XTe as described in chapter 5 of this manual – for that, *MIC* must be selected. If a condenser microphone that requires power supply is connected, the +48V switch must be enabled to enable phantom power. Note that +48V should be enabled only after a condenser microphone has been connected. Never enable +48V when a dynamic microphone or no microphone at all is connected to MAYA44 XTe. Input channel 1/2 can also process the digital input signal from the coaxial S/PDIF input of MAYA44 XTe. For that, *DIGITAL* must be selected.

Line/Guitar selection: by default, input channel 3/4 is processing the stereo line input signal coming in from *INPUT 3/4* (when *LINE* is selected). However, it can also be switched to process the mono input signal from a guitar connected to MAYA44 XTe as described in chapter 5 of this manual – for that, *GUITAR* must be selected.

Gain knobs: as the output level of a microphone typically is very low and requires amplification, the gain knobs allow you to control the built-in amplifier in order to raise and match the input signal in order for the signal to be further processed. The range is from 0dB to +24dB amplification. The 2 gain knobs are not available under Mac OS X, instead the level faders (below) are longer.

Level faders: these faders allow you to adjust the input level for the analog input 1/2 and 3/4. The levels can be set using the mouse, mouse wheel, or cursor keys. Depending on the *Link* setting (refer to section 6.1), you can control left an right channels simultaneously or independently.

Mute buttons: this button allows you to mute the input signal on channel 1/2 or on channel 3/4. When the button is red, mute is enabled – otherwise disabled.

6.3 Output Section

Mix buttons: with these buttons it is possible mix the output 1/2 and 3/4 signals to each other. This is especially important if you want to listen to the same signal played through only one channel pair on both outputs, especially with headphones connected to one of the outputs. When *Mix* is enabled, the blue arrow will display that the signal is transferred to the other channel.

Mix level knobs: controls the level for mixed signal to adjust the level that you wish to send to the other channel. Make sure not to confuse the mix knobs with the gain knobs in the input section.

Level faders: these faders allow you to adjust the playback level for the analog output 1/2 and 3/4 signals. The levels can be set using the mouse, mouse wheel, or cursor keys. Depending on the *Link* setting (refer to section 6.1), you can control left an right channels simultaneously or independently.

Mute buttons: this button allows you to mute the output signal on channel 1/2 or on channel 3/4. When the button is red, mute is enabled – otherwise disabled.

6.4 Digital Section

Digital Out section: here you can select the source for the optical and coaxial S/PDIF output. It can either be *from OUT 1/2* or *from OUT 3/4*, depending on the selection. The MAYA44 XTe S/PDIF output is capable to send out professional (*PRO*) and consumer (*CON*) status bits, depending on the selection. Some digital devices will only process either one of the two signal types on their S/PDIF input.

Digital In section: allows you to select the digital input source. When this is set to *Loopback*, the digital input signal will be internally taken from the S/PDIF transmitter – this means that you can internally record and process 1:1 copies on a pure hardware level inside the MAYA44 XTe hardware. The recommended and default setting is *External*, as it processes the signal from the physical coaxial S/PDIF input from MAYA44 XTe instead. Below that, the *status* area displays the current S/PDIF input signal state.

6.5 DirectWIRE

What is DirectWIRE?

DirectWIRE is a driver technology, developed by ESI, which can be used for routing audio streams internally within applications using EWDM Audio MIDI Drivers exclusively developed by ESI.


With the DirectWIRE router, an application can record from other application's audio outputs without external wiring or any loss of data when they are running at the same time.

DirectWIRE also allows you to easily rip any audio stream in real time by transferring data thru DirectWIRE from MP3s, live On-line Broadcast and On-demand content, and more.

DirectWIRE is not available under Mac OS X.

DirectWIRE Panel

Click on *DirectWIRE* on the MAYA44 XTe control panel. The DirectWIRE dialog as shown below will appear. DirectWIRE digital virtual wiring technology, developed by ESI, routes audio streams internally within applications using standard audio drivers such as WDM, ASIO and MME, even when they are running at the same time.



The number on the row represents the input or output port. The columns represent ins and outs (on and off) of the respected drivers. Patch the virtual cables from one point to another as you drag your mouse point.

INPUT section: It's used to route signals from the card's hardware inputs.

MME section represents general application's I/O: Ex.) WinAmp, WaveLab (non ASIO mode), Cakewalk, Audition, Vegas, etc.

WDM section represents Multi-MME application's I/O: Ex.) SONAR (when using WDM/KS), PowerDVD, WinDVD, etc.


ASIO section represents ASIO application's I/O: Ex.) Cubase, Logic, Reason, Nuendo, SONAR (when using ASIO), Samplitude, etc.

GSIF section represents GSIF application like GigaStudio.

Note that some applications support multiple driver modes.

DirectWIRE Examples



Example 1. Recording from WinAmp (MME) to WaveLab (MME).



If you want to record what's played back in WinAmp, but don't want to hear the sound, you should click the *OUT* button in the MME section so it'll change to *OFF*.

Example 2. Recording from WinAmp (MME) to SONAR (WDM).

Example 3. Recording from WinAmp (MME) to Cubase, Logic, Nuendo (ASIO).





Example 4. Recording from GigaStudio (GSIF)

Example 5. Recording from GigaStudio (GSIF)

to SONAR (WDM).

to Cubase (ASIO).



7. Audio Applications

This chapter contains basic configuration examples for some software applications. Please also refer to the manual of the audio software you use for detailed information.

7.1 Windows Multimedia Setup

The Windows multimedia setup is required if you want to use your MAYA44 XTe as the main sound device for Windows multimedia applications. Go to *My computer* -> *Control panel* -> *Sounds and Audio Device Properties* -> *Audio*. Select the MAYA44 XTe entry as your playback device to make sure that all standard signals are played via the MAYA44 XTe hardware.

Please note that some advanced properties buttons in this area will be grayed out because some of the mixer features of MAYA44 XTe are not compatible with the functions provided by the Windows default mixer that was designed for consumer audio hardware. However, this does not mean you do not have any advanced options - the MAYA44 XTe control panel described in the previous chapter includes all professional audio features that you might need and which are simply not always compatible with the basic mixer control from Windows.

7.2 Mac OS X Audio MIDI Setup

The *Audio MIDI Setup* application can be found in the *Utilities* folder on your system. When you launch it, you can setup MAYA44 XTe as your *Default Input*, *Default Output* or *System Output* device – if required.

While audio production and editing applications usually provide an option inside their preferences to select MAYA44 XTe as recording and playback device, many general standard applications such as iTunes for example are usually accessing the *Default Output* device, selectable in the *Audio MIDI Setup* dialog.

If you want to change settings of MAYA44 XTe, you need to select it under *Properties For*. You can change the default sample rate under *Audio Input* -> *Format* or *Audio Output* -> *Format* or you can change the main playback volume under *Audio Output* -> *Volume Slider* -> *M*.

7.3 Cubase LE 6

MAYA44 XTe ships with a DVD-ROM with Cubase LE 6 from Steinberg. If you are using a different recording software, you can skip this section.

Installation

To install Cubase LE 6, insert the DVD-ROM into the DVD-ROM drive of your computer. Under Windows, the installation will normally start automatically – if not, you can launch it manually by starting the installer from the DVD-ROM drive. To install Cubase LE 6 under Mac OS X, double click on the installer icon

To proceed with the installation, follow all instructions on screen. During the installation the *Syncrosoft License Control* software will be installed as well. To use Cubase LE 6 for more than 30 days, you need to activate it with this software via the internet. This means that you need an active internet connection on the computer you are installing Cubase LE 6. We recommend you to activate the software as early as possible.

Initial Setup

As most digital audio applications, Cubase LE 6 requires some initial configuration, before it can be used properly with a new audio interface like MAYA44 XTe. Start Cubase LE 6 and select *Device Setup* from the *Devices* menu. Select *VST Audio System* on the tree structure on the left part of the window and then make sure to select *ESI MAYA44 XTe ASIO* as *ASIO Driver* entry. You can verify your selection by selecting the *ESI MAYA44 XTe* device on the left. The dialog, now lists all input and output channels. Note that the *Control Panel* button has no effect. Confirm your changes by clicking *OK*.

After that its time to select the input and output channels. From the *Devices* menu, select *VST Connection*. The *VST Connections* window appears. Configure your input bus in the *Inputs* tab and your output bus under *Outputs*. A bus can be either mono or stereo and added with *Add Bus*.

After that you can start using Cubase LE 6 by opening an existing project or creating a new project. The input and output busses you have created can be assigned to the individual tracks of your project.

8. Specifications

<Analog Audio>

1. Sample Rates
 - 32, 44.1, 48, 88.2, 96 kHz recording & playback
2. Analog Input
 - 1) connector type: 4 channel analog inputs
 - * 1/4" TRS (stereo) jack (line in 1 and 2) common with microphone input
 - * 1/4" TRS (stereo) jack (line in 3 and 4) common with Hi-Z input
 - 2) peak level: 0dBFS @ +6dBV
 - 3) programmable gain: -48dB ~ +24dB (1dB step size)
 - 4) impedance: 10K Ohm
3. Analog Output
 - 1) connector type: 4 channel analog line outputs

- * 1/4" TRS (stereo) jack
- 2) peak level: +6dBV @ 0dBFS
- 3) attenuation: -48dB ~ +0dB (1dB step size)
- 4) impedance: 33 Ohm (line out 1 and 2, headphone out), 33 Ohm (line out 3 and 4, headphone out)
- 4. Microphone Preamp
 - 1) mic preamp gain: +21dB
 - 2) peak level: 0dBFS @ 246mV
 - 3) +48V phantom power supply
 - 4) impedance: 3.3K Ohm
- 5. Hi-Z / Guitar Input
 - 1) impedance: min. 330K Ohm
- 6. Headphone Amplifier
 - 1) load impedance range: 32-300 Ohm (for best performance)
 - 2) output power: 125mW @ 32 Ohm per channel

<Digital Audio>

1. Sample Rates
 - 1) 32, 44.1, 48, 96 kHz input and output
2. A/D Converter
 - 1) SNR: 102dBA (0dB @ fs=48kHz)
 - 2) dynamic range: 102dBA
 - 3) THD: -95dB (1kHz, -1dBFS)
 - 4) interchannel isolation: 90dB
3. D/A Converter
 - 1) SNR: 108dBA (0dB @ fs=48kHz)
 - 2) dynamic range: 108dBA
 - 3) THD: -97dB(1kHz, 0dBFS)
 - 4) interchannel isolation: 100dB
4. Digital Input
 - 1) connector type: optical Toslink
 - 2) format: IEC-60958 Consumer (S/PDIF)
 - 3) resolution: 24-Bit
5. Digital Output
 - 1) connector type: optical Toslink
 - 2) format: IEC-60958 Consumer (S/PDIF)
 - 3) resolution: 24-Bit
 - 4) digital pass thru

9. General Information

Trademarks

ESI, and MAYA44 XTe are trademarks of ESI Audiotechnik GmbH. Windows is a trademark of Microsoft Corporation. Other product and brand names are trademarks or registered trademarks of their respective companies.

The FCC and CE Regulation Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution : Any changes or modifications in construction of this device with are not expressly approved by the party responsible for compliance, could void the user's authority to operate equipment.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. If necessary, consult an experienced radio/television technician for additional suggestions.

Correspondence

For technical support inquiries, contact your nearest dealer, local distributor or ESI support online at www.esi-audio.com.

Disclaimer

All features and specifications subject to change without notice.

Parts of this manual are continually being updated. Please check our web site www.esi-audio.com occasionally for the most recent update information.